

















## USE AND MAINTENANCE:


🌡️ 18-30°C 💧 40-65%




The Afimrax floor may be cleaned with a vacuum cleaner, however, it is prohibited to use steam cleaning devices.




The Afimrax floor can be cleaned with a damp or wet mop.



The movement of heavy objects along the floor is not allowed. They must be moved only after they are lifted.



Used office chairs with W-type castors, protecting the floor additionally by means of the protective net. The furniture legs must be provided with protective pads which provide protection against scratching, e.g. made of felt.



After laying the floor and waiting 24 hours, you can turn on the underfloor heating, remembering to gradually increase the temperature (5°C per day).  
**ATTENTION!** It should be remembered that the maximum temperature of the floor surface is 27°C.